



EZEE TILE

SELF LEVELLING SCREED

TECHNICAL DATA SHEET

PURPOSE

EZEE TILE SELF LEVELLING SCREED® is a high strength, quick setting cement based compound designed for levelling imperfect floors. When properly applied, it will produce a smooth hard underlayment suitable for laying tiles, carpets and wooden flooring. This product can be applied up to 10mm thick in a single application.

MIXING INSTRUCTIONS



1. Gradually add 20 Kg of EZEE TILE SELF LEVELLING SCREED® into 4.8 Lt of cold water.
2. Mix to a creamy lump-free slurry consistency. The use of an electric drill and paddle is recommended to ensure thorough mixing.
3. Allow to stand for 5 min.
4. Re-mix for a further 2 -3 min at low speed.
5. Use within 20 min. If the product thickens, DO NOT ADD MORE WATER - rather stir thoroughly to extend pot life.
6. NOTE: if a white film appears upon the surface of the screed, then too much water has been added. To rectify, add small portions of EZEE TILE SELF LEVELLING SCREED® and remix to achieve a smooth flowable consistency with a uniform colour.

*This guideline only serves as a basic manual for the surface preparation, product selection and installation procedure for this type of application. Each installation needs to be assessed on merits and the products used and the procedures followed should be in accordance with the SABS code for the design and installation of ceramic tiles (SABS 10107:2011).

SURFACE PREPARATION

(These recommendations are in accordance with the SABS standard SANS 10107:2011 - The design and installation of ceramic tiles.)

1. Ensure that floor to be screeded is sound (no cracks or crumbling), clean, free of dust, release agent, fungi, or any surface dampness. Fungi must be removed and the spores killed with the use of an effective fungicide. (a dilution of household bleach is sufficient)

2. New concrete floors must be allowed to cure for minimum periods as listed below to ensure that movement due to shrinkage does not affect the installation

a. New screeded floors:

4 weeks

3. Very smooth surfaces such as steel trowelled and off-shutter concrete must be acid washed to remove laitance and then rinsed thoroughly with cold water. The surface must then be primed with a mixture consisting of 2 parts EZEE TILE BASECOAT[®] mixed with one part EZEE TILE KEYCOAT[®] and allowed to dry prior to screeding.

4. Painted surfaces, gypsum plasters and surfaces that have old bitumen adhesive on them must be chipped in order to expose at least 80% of the substrate. The surface must then be primed with a mixture consisting of 2 parts EZEE TILE BASECOAT[®] mixed with one part EZEE TILE KEYCOAT[®] and allowed to dry prior to screeding.

5. Highly porous substrates can negatively affect the bond strength between the screed and substrate. Check the porosity of the substrate by applying a small quantity of water. If the moisture is completely absorbed within one minute, then the surface is too porous and will need to be sealed with a mixture of 2 parts EZEE TILE BASECOAT[®] mixed with one part EZEE TILE KEYCOAT[®] and allowed to dry prior to screeding.

APPLICATION

1. Pour the EZEE TILE SELF LEVELLING SCREED[®] onto the floor and allow to flow and fill the application area.

2. Use an extended trowel to work the product into a smooth surface.

3. Further rolling of the screed with a spiked roller is recommended to remove excess air and to increase the screed's density. This will improve surface smoothness and increase the compressive strength of the screed.

4. For large areas, separately mix 2- 3 bags at a time. This will assist in ensuring smooth joints between bags during application.


5. EZEE TILE SELF LEVELLING SCREED[®] can be applied up to a thickness of 10mm in one application. For thicker applications, apply in steps of 10 mm layers until the desired level is reached. Allow to completely dry before applying the next layer.

6. All structural or movement joints should be identified prior to application and then maintained by saw cuts through the dried screed.

7. For heavy duty applications, replace the mixing water with EZEE TILE BONDING LIQUID[®]. The flow characteristics of the screed may reduce slightly and de-aeration with a spike roller is recommended.

8. Allow 24 hours before tiling.

*This guideline only serves as a basic manual for the surface preparation, product selection and installation procedure for this type of application. Each installation needs to be assessed on merits and the products used and the procedures followed should be in accordance with the SABS code for the design and installation of ceramic tiles (SABS 10107:2011).



As a guide, a 20 kg bag of EZEE TILE SELF LEVELING SCREED® will cover approximately 3.5 m² when applied onto a relatively even surface to a thickness of 3mm.

GENERAL APPLICATION INFORMATION

Please note that the performance of this product is strongly dependent upon the climatic conditions during application and upon the temperature of the substrate and mixing water. Do not apply this product when the ambient temperature or the temperature of the floor is below 10°C. The mixing water should be at room temperature i.e. 20 - 25°C. Warm water, high ambient temperatures and windy conditions will reduce setting times and negatively affect this product's strength development. This product has not been designed to be a final floor finish.

TECHNICAL DATA

Initial setting time	± 1.5 hours at 25°C and 50% humidity
Final Setting Time	± 6 hours at 25°C and 50% humidity
Pot Life	± 30 hours at 25°C and 50% humidity
Mixing Ratio	4.8 Lt of water to 20kg bag
Storage	Store dry
Shelf life	9 months in dry moderate conditions
Packaging	20 kg

PRECAUTIONS

1. Ensure that the above instructions are adhered to at all times and do not adulterate the product in any way as this could result in failure.
2. Rubber gloves should be used when applying EZEE TILE SELF LEVELLING SCREED®. In the event of irritation, rinse skin under cold water. Consult a doctor if irritation persists.
3. Keep EZEE TILE SELF LEVELLING SCREED® away from pets and children.
4. Do not ingest and do not empty surplus adhesive down drains.

*This guideline only serves as a basic manual for the surface preparation, product selection and installation procedure for this type of application. Each installation needs to be assessed on merits and the products used and the procedures followed should be in accordance with the SABS code for the design and installation of ceramic tiles (SABS 10107:2011).

